


CT100 Supplemental Instructions



Common Wiring Configurations

- Two wire boilers should be connected to R and W1
- Three wire furnace w/o AC should be connected to R, W1, Y
- Four wire furnace with AC should be connected to R, W1, Y and G

Thermostat Terminals	
R	24v (Hot)
C	24vac (Optional Common)
W1	Heat Relay
Y	Cool Relay
G	Fan Relay

Note: Before removing your old thermostat, label which wires are connected to which terminals. You should connect the wires to the same terminals on the CT100.

The color of the wires do not matter. What matters is what function the wire performs.